



PRODUCT ASSEMBLY INSTRUCTIONS:



www.wavearmor.net

Item # | Product Name: #301262 Heritage Post Cover Kit

Parts List:	Tools Needed:
1. #301234 Heritage Post Cover qty 2	1. Mallet
2.	2.
3.	3.
4.	4.
5.	5.

Assembly Instructions:

1. Position cover over the dock post and the 2” post attachment insert. The post cover is designed to fit over 2” pipe. Use the mallet to tap the post cover on if necessary. Align the eyelets on the side as desired.

